


NOTE:

1. AS ROOF SHEETS ARE BEING INSTALLED, LOCATE ROOF CURB OPENING AND INSTALL SUPPORT FRAMING FOR CURB AND EQUIPMENT LOADS. AVOID CANTILEVER SECTIONS OVER 1'-0" IN LENGTH.
2. CURB FASTENERS ARE NOT SHOWN FOR CLARITY.
3. ALLOW SUFFICIENT SPACE FOR DRAINAGE AT BOTH SIDES OF ALL ROOF PENETRATIONS.
4. PENETRATION FLASHINGS MAY REQUIRE ADDITIONAL SUPPORT OR FRAMING.



**MULTILOK-24**



**CURB**

**ML-18**